

# THE HARWICK CO.®

INSTALLATION DRAWING FOR CASEMENT LOCKS.  
CUT TEMPLATE IN HALF ALONG CUT LINE  
FOLD ALONG DOTTED LINE  
PLACE THE TEMPLATE AGAINST THE INSIDE OF THE SIDE JAMB  
MAKE SURE THAT THE UP DOWN ARROWS ARE FACING CORRECTLY.  
USE AN ALL TO PUNCURE THE PAPER AT THE FOUR + MARKS  
INDICATING THE FOUR SCREW HOLES  
DRILL FOUR 7/64" HOLES INSTALL THE KEEPER FLAT SIDE OUT.  
INSTALL THE CASEMENT LOCK  
CHECK OPERATION OF LOCK

